



## Zoom 6000


Basic Zoom 6000 configuration




Zoom 6000 configuration with coaxial illumination



Zoom 6000 configuration with motorization




Zoom 6000 configuration with motorization and right angle adapter




## 12X Zoom


Basic 12X Zoom configuration



12X Zoom configuration with coaxial illumination



12X Zoom configuration with motorization



12X Zoom configuration with motorization and right angle adapter

