

Polytec EC 151-L

Properties

Polytec EC 151-L is a standard two-component, solvent free epoxy resin optimized for stamping application, with a long pot life, high temperature stability and excellent electrical conductivity.

It can be used for high volume chip and substrate bonding, in micro-electronic, hybrid and optoelectronic application.

Polytec EC 151-L can be cured at 95°C or allows rapid cure cycles at higher temperatures and will withstand reflow and wire bond processes.

The material can be applied by stamping, (jet-) dispensing or manually.



Processing

- For two-component products the components A and B should be mixed carefully within the specified mixing ratio.
- For filled products both components should be homogenized carefully prior mixing, in order to prevent a possible settling of the filler.
- Processing should be carried out rapidly after mixing the components; as an indication the pot life can be used.
- Surfaces should be clean, thus free of dirt, grease, oil, dust or process chemicals.
- One-component products can be applied directly and are not subject to a pot life (except pre-mixed/frozen products).
- Please take notice of respective minimum curing temperature and time.
- For Safety information please refer to the respective Material Safety Data Sheet.

Polytec EC 151-L

Electrically Conductive Adhesive

Technical Data

Polytec EC 151-L

Properties in uncured state	Method	Unit	Technical Data
Chemical basis	-	-	Epoxy
No. of components	-	-	2
Mixing ratio (weight)	-	-	1:1
Mixing ratio (volume)	-	-	-
Pot life at 23°C	TM 702	h	48
Storage Stability at 23°C	TM 701	months	12
Consistency	TM 101	-	Creamy Paste
Density Mix	TM 201.2	g/cm ³	2.81
Density A-Part	TM 201.2	g/cm ³	-
Density B-Part	TM 201.2	g/cm ³	-
Type of filler	-	-	Silver
Max. particle size	-	µm	<40
Viscosity Mix 84 s ⁻¹ at 23°C	TM 202.1	mPa·s	5 000
Viscosity A-Part 84 s ⁻¹ at 23°C	TM 202.1	mPa·s	7 500
Viscosity B-Part 84 s ⁻¹ at 23°C	TM 202.1	mPa·s	6 000

Properties in cured* state	Method	Unit	Technical Data
Color	TM 101	-	Silver
Hardness (Shore D)	DIN EN ISO 868	-	85
Temperature resistance continuous	TM 302	°C	-55 / +200
Temperature resistance short term	TM 302	°C	-55 / +300
Degradation Temperature	TM 302	°C	+400
Glass Transition Temperature (T _g)	TM 501	°C	75
Coefficient of thermal expansion (<T _g)	ISO 11359-2	ppm	40
Coefficient of thermal expansion (>T _g)	ISO 11359-2	ppm	114
Thermal conductivity	-	W/m·K	-
Specific volume resistivity	DIN EN ISO 3915	Ω·cm	3 – 6 · 10 ⁻⁴
Electrical conductivity	DIN EN ISO 3915	S/m	-
Elasticity modulus	TM 605	N/mm ²	7 000
Tensile Strength	TM 605	N/mm ²	32
Lap shear strength (Al/Al)	TM 604	N/mm ²	-
Elongation at break	TM 605	%	0.5
Water absorption 24 h, 23°C	TM 301	%	0.4

*The above data has been determined with samples cured at 150°C. Please notice, by varying the curing temperature these properties can be influenced to some extend.

Polytec EC 151-L

Curing*	Method	Unit	Technical Data
Minimum curing temperature		°C	95
Curing time at 100°C		min	60
Curing time at 120°C		min	15
Curing time at 150°C		min	5
Curing time at 180°C		s	60

*Curing temperatures refer to the temperature in the respective bond line. When choosing the respective curing conditions, the time needed to heat the substrate has to be considered. Depending on the type of heat source (convection oven, hot stamp, heating plate) the heat input may vary.

Standard pack sizes:

30 g, 250 g, 500 g

Customized Packaging

Please note:

The above listed information are typical data based on tests and are believed to be accurate. Polytec PT makes no warranties (expressed or implied) as to their accuracy. The above listed data do not constitute specifications. The processing (in particular the cure conditions) of the material, the process control and the variety of different applications at various customers are not under Polytec PT's control. Therefore Polytec PT will not be liable for concrete results in any specific application or in any connection with the use of this product. In particular the cure conditions do have a major effect on the properties of the cured material. Therefore it is highly recommended to keep the cure schedule – once established - under tight control. With the release of this data sheet all former data sheets will be null and void.

Subject to alteration.

Polytec PT GmbH
Polymere Technologien
Ettlinger Straße 30
76307 Karlsbad
Germany
Tel. +49 (0) 7243 604-4000
Fax +49 (0) 7243 604-4200
info@polytec-pt.de
<http://www.polytec-pt.de>

Polytec France S.A.S.
TECHNOSUD II
Bâtiment A
99, Rue Pierre Semard
92320 Châtillon - France
Phone. +33 (0)1 49 65 69 00
Fax +33 (0)1 57 19 59 60
info@polytec.fr
<http://www.polytec-pt.com>

Polytec South-East Asia Pte Ltd
Blk 4010 Ang Mo Kio Ave 10
#06-06 Techplace I
Singapore 569626
Tel. +65 6451 0886
Fax +65 6451 0822
info@polytec-sea.com
<http://www.polytec-pt.com>