



PRODUCT DATA SHEET

Hyperspec[®] VNIR Hyperspectral Imaging Sensor




VNIR E-Series


- Spectral Bands: 837 (A-Series) or 923 (E-Series)
- Spatial Bands: 1004 (A-Series) or 1600 (E-Series)
- Max Frame Rate: up to 160 depending on version
- Aberration-corrected imaging
- All-reflective concentric optical design
- Collect full spectrum for every pixel in FOV

Hyperspec[®] VNIR

Model	A Series	E Series
Wavelength Range (nm)	380-1000	
Aperture	F/2.0	
Entrance Slit Width	25 microns	
Dispersion/Pixel (nm/pixel)	0.74	0.65
FWHM spectral resolution	2.5nm	
Slit Length	12mm	
Spectral Bands	837	923
Spatial Bands	1004	1600
Smile - Aberration-corrected	Yes	
Keystone - Aberration-corrected	Yes	
FPA Detector	CCD	sCMOS
Max. Frame Rate (Hz)	57 (no binning); 90 bin x2	160
Pixel Pitch (microns)	7.4	6.5
Camera Control Interface	Base Cameralink	Full Cameralink, 80-bit
Weight (lb / kg)	6.1 / 2.8	8.5 / 3.9
Max. Power (W)	6.6	20



Headwall-manufactured diffraction gratings manage reflected light with exceptional precision and resolution.



Headwall's concentric design layout using mirrors and gratings provides aberration-free imaging and a wide field-of-view.



Telecentric lens provides a perfectly matched exit pupil that eliminates unwanted image artifacts.

January 2018

© 2018 Headwall Photonics, Inc. Information in this document is subject to change without notice. Headwall Photonics, Inc. reserves the right to change or improve its products and specifications and to make changes in content without obligation to notify any person or organization of such changes or improvements. The Hyperspec[®] name (and all its derivations) is a registered Trademark of Headwall Photonics, Inc. *US and/or EU Export Restrictions may apply to this Dual Use Product.