





TTO-120




FEATURES

- Full map in one measurement
- Low stray light / Easy setup
- Fast measurements
- High color & luminance accuracy

APPLICATIONS

- Full screen Normal measurements.
- VESA / ICDM-IDMS standards compliance tests
- Sampled Uniformity tests (all measurements taken normal to the screen)
- Ideal for the mobiles & tablets quality control

ELDIM proposes different double telecentric optics for imaging colorimeter. The interest of such optics is twofold: the measurement is taken near normal incidence on the entire display surface; the stray light is minimized allowing measurements on complex color patterns with a high spatial resolution and very small distortion.



ELDIM

OPTICAL METROLOGY FOR DISPLAYS

