

Polytec UV 2144

Properties

Polytec UV 2144 is a fast curing, single component, UV-/ Visible light curable, high viscosity epoxy/acrylic adhesive. The product has a high Tg, high-strength performance, good resistance against chemical and elevated temperatures.

Polytec UV 2144 has a good adhesion to glass, metals and most plastics and starts to cure at low intensity.

Polytec UV 2144 is an adhesive, sealant and encapsulant for sensitive parts and as protection against harsh environments.



Processing

- Polytec UV adhesives are singlecomponent products which cure rapidly under exposure to UV or visible light. They should not be exposed to light before application.
- Polytec UV adhesives come ready to use and can be applied directly from the respective packaging.
- Been refrigerated products should be brought to room temperature prior to processing.
- The curing time depends on a number of factors such as type and intensity of the light source, working distance for UV lamp, adhesive layer thickness and UV transmittance of the substrate.
- Air oxygen may inhibit the curing of the material at the surface. Surfaces associated with air during the hardening should be cured with higher intensity or by using an inert gas (e.g. nitrogen) to obtain a dry surface. Please take notice of respective minimum curing temperature and time.
- Substrates should be free of dirt, grease, oil or any flux residues.
- For Safety information please refer to the respective Material Safety Data Sheet.

Polytec UV 2144
UV light curing acrylate adhesive
Technical Data



Polytec UV 2144

| Properties in uncured state | Method | Unit | Technical Data |
|--|----------|--------|--------------------|
| Chemcical basis | - | - | Acrylate / Epoxide |
| No. of components | - | - | 1 |
| Storage Stability at 23°C | TM 701 | Months | 12 |
| Consistency | TM 101 | - | Highly viscous |
| Density Mix | TM 201.2 | g/cm³ | 1.05 |
| Viscosity Mix 60 s ⁻¹ at 23°C | TM 202 | mPa∙s | 15 000 |

| Properties in cured* state | Method | Unit | Technical Data |
|---|----------------|-------|----------------|
| Color | TM 101 | - | Transparent |
| Hardness (Shore A after UV-curing) | DIN EN ISO 868 | - | 83 |
| Temperature resistance continuous | TM 302 | °C | -40 / +150 |
| Temperature resistance short term | TM 302 | °C | F |
| Degradation Temperature | TM 302 | °C | - |
| Glass Transition Temperature (T_g) | TM 501 | °C | 167 |
| Coefficient of thermal expansion (<t<sub>g)</t<sub> | ISO 11359-2 | ppm | F |
| Coefficient of thermal expansion (>T _g) | ISO 11359-2 | ppm | F |
| Elasticity modulus | TM 605 | N/mm² | F |
| Tensile Strength | DIN 53455 | N/mm² | F |
| Lap shear strength (PC/Aluminium) bei 23 °C (PC/Aluminium) bei 125 °C | DIN 53283 | N/mm² | 5.5 3.5 |
| Elongation at break | TM 605 | % | F |
| Water absorption 24 h, 23°C | TM 301 | % | 0.3 |
| Refractive Index | - | = | F |

^{*}The above data has been determined with samples cured by UV-light. Please notice, by varying the curing temperature these properties can be influenced to some extend.



Polytec UV 2144

| Curing* | Method | Unit | Technical Data |
|----------------------------------|--------|------|----------------|
| Emission spectrum | | nm | 320 – 500 |
| Maximum | | nm | 350 - 420 |
| Curing time at 0.05 mm thickness | | S | ca. 5 |

^{*}Curing temperatures refer to the UV-light intensity in the respective bond line. When choosing the respective curing conditions, the thickness and the substrates permeability towards UV-light has to be considered.

Standard pack sizes:

30cc* / 30g, 20oz***/500g, 32oz***/950g

Customized Packaging

*: EFD-Cartridges, **: Bottles, ***: Semco-Cartridges

Please note:

The above listed information are typical data based on tests and are believed to be accurate. Polytec PT makes no warranties (expressed or implied) as to their accuracy. The above listed data do not constitute specifications. The processing (in particular the cure conditions) of the material, the process control and the variety of different applications at various customers are not under Polytec PT's control. Therefore Polytec PT will not be liable for concrete results in any specific application or in any connection with the use of this product. In particular the cure conditions do have a major effect on the properties of the cured material. Therefore it is highly recommended to keep the cure schedule – once established - under tight control. With the release of this data sheet all former data sheets will be null and void.

Subject to alteration.

Polytec PT GmbH
Polymere Technologien
Ettlinger Straße 30
76307 Karlsbad
Germany
Tel. +49 (0) 7243 604-4000
Fax +49 (0) 7243 604-4200
info@polytec-pt.de
http://www.polytec-pt.de

Polytec France S.A.S.
TECHNOSUD II
Bâtiment A
99, Rue Pierre Semard
92320 Châtillon - France
Phone. +33 (0)1 49 65 69 00
Fax +33 (0)1 57 19 59 60
info@polytec.fr
http://www.polytec-pt.com

Polytec South-East Asia Pte Ltd Blk 4010 Ang Mo Kio Ave 10 #06-06 Techplace I Singapore 569626 Tel. +65 6451 0886 Fax +65 6451 0822 info@polytec-sea.com http://www.polytec-pt.com