



HSV-100 High Speed Vibrometer

Optical Vibration Measurement at High Speeds Product Brochure





Intelligent Valvetrain Measurement

High speed vibrations of up to 40 m/s are recorded by the HSV-100 High Speed Vibrometer rapidly and without contact. It is the instrument of choice for the analysis of valve motion in combustion engines, impact strength studies, operational reliability tests and the investigation of all processes which involve high energies and hence high motion velocities.

Internal combustion engines are designed today for energy and power efficiency over a wide load range. The HSV-100 precisely determines critical valve elevation curves and valve closing dynamics. Its wide dynamic range enables the reliable analysis of phenomena such as valve bounce, which occurs at frequencies in the kHz range.

Clear Results

The HSV-100 simultaneously measures motion of the valve head and cylinder head. The high resolution differential signal reflects the real valve motion relative to the cylinder head.

More Knowledge

An arbitrary number of HSV-100s can be interconnected to form a multi-channel measurement system. Productivity is increased and timing problems between individual valves are exposed.

Swift Integration

The HSV-100 exclusively uses voltage signals, which are easily integrated into existing data management systems.



Features and Benefits

High Resolution Real-time Measurements

- Non-invasive measurement of dynamic velocity and displacement quantities
- Modern digital decoding technology
- Tracking filter guarantees reliable results even from difficult surfaces

Flexible Use

- Compact sensor is good for restricted space conditions
- Suitable for industrial applications with IP64 rated sensor head
- Frequency bandwidth 50 kHz, optional 250 kHz
- Variable focus

Easy Setup

- Signal level display at controller front panel and sensor facilitate aiming and adjusting the setup
- Visible measurement spot for point and shoot operation
- Optional HSV-AK-800 beam deflection unit especially well suited for engine test benches

Reliable and Safe Operation

- Signal level output for monitoring and recording signal quality
- Large working distance protects equipment in hazardous areas
- Eye-safe class 2 laser

Accurate Differential Measurement

- Compensates for test bench motion
- Synchronized measurement of an arbitrary number of channels with correct phase relation
- Vibration velocity and displacement output at the same time



Polytec GmbH (Germany)

Polytec-Platz 1-7 76337 Waldbronn Tel. +49 7243 604-0 info@polytec.de

Polytec GmbH (Germany) Vertriebs- und Beratungsbüro

Schwarzschildstraße 1 12489 Berlin Tel. +49 30 6392-5140

Polytec, Inc. (USA)

North American Headquarters 16400 Bake Parkway Suites 150 & 200 Irvine, CA 92618 Tel. +1 949 943-3033 info@polytec.com

Central Office

1046 Baker Road Dexter, MI 48130 Tel. +1 734 253-9428

East Coast Office

25 South Street, Suite A Hopkinton, MA 01748 Tel. +1 508 417-1040

ЭĘ

Polytec Ltd. (Great Britain)

Lambda House Batford Mill Harpenden, Herts AL5 5BZ Tel. +44 1582 711670 info@polytec-ltd.co.uk

Polytec France S.A.S.

Bâtiment Orion – 1er étage 39, rue Louveau 92320 Châtillon Tel. +33 1 496569-00 info@polytec.fr

Polytec Japan

Arena Tower, 13th floor 3-1-9, Shinyokohama Kohoku-ku, Yokohama-shi Kanagawa 222-0033 Tel. +81 45 478-6980 info@polytec.co.jp

Polytec South-East Asia Pte Ltd

#U AUTO Ang Mo Kio Ave 10 #06-06 TechPlace 1 Singapore 569626 Tel. +65 64510886 info@polytec-sea.com

Polytec China Ltd.

Room 1026, Hanwei Plaza, No. 7 Guanghua Road Chaoyang District, 100004 Beijing Tel. +86 10 65682591 info-cn@polytec.com