

# USB3.0 UV CMOS Camera

## ARTCAM-2020UV-USB3

### INSTRUCTION BOOKLET

4.00 M Pixels

ARTCAM-2020UV-USB3

# Contents

1. Attention .....	- 3 -
2. Introduction.....	- 6 -
3. Main Features .....	- 6 -
4. The Product.....	- 6 -
5. Connections .....	- 7 -
5.1. Connecting Method (an example) .....	- 7 -
6. Specifications .....	- 8 -
6.1. Camera Specifications .....	- 8 -
6.1.1. Detailed Camera Specifications .....	- 8 -
6.1.2. Dimensional Outline .....	- 9 -
6.1.3. Schematic Diagram of the Sensor .....	- 10 -
6.2. Camera's Functions.....	- 11 -
6.2.1. Shutter Speed.....	- 11 -
6.2.2. External Trigger Function (Optional) .....	- 11 -
7. Spectral Sensitivity Characteristics.....	- 13 -
7.1. ARTCAM-2020UV-USB3.....	- 13 -
7.2. UV Pass Filter (U340) (Optional) .....	- 13 -
8. Systems Requirements.....	- 14 -
8.1. Recommended Specifications .....	- 14 -
8.2. Minimum Specifications .....	- 14 -

# 1. Attention

## ■About this Manual

1. Before using the camera, please read this manual thoroughly.
2. Please keep this manual reachable and always refer to the contents when needed.
3. Please contact us if the manual is lost or damaged. We will provide a replacement.
4. We cannot guarantee the safety of improper uses of the camera.
5. For your safety, please follow the directions of this manual.
6. All contents are subject to change.
7. Images in this manual may have been simplified to be easier comprehended.
8. Please contact us if you find any unclear points or mistakes in this manual.
9. Quoting, copying or altering some or all parts of the manual without our permission is prohibited.
10. We are not responsible for any lost or damages on your profits due to the use of our products.
11. Please understand that our oversea branches do not provide maintenance or repair services.

## ■About the Icons

To keep the safety of the user, other people and their properties, please pay attention to the following icons.



## Warning

If the user fails to follow the instruction, serious injury or death may occur.



## Caution

If the user fails to follow the instruction, physical injury on human or damages on hardware may occur.

■For Safe Use



## Warning

●In following circumstances, please stop using the product and turn off the power immediately to prevent the risks of fires and electric shocks. If the product is defective, please contact us for repair or exchange. For your safety, please do not disassemble, modify or repair the camera on your own.

Please stop using the product and turn off the power immediately when:

- The product becomes smoky or gets extremely hot on the surface, or makes unusual smells or sounds.
- Foreign material or water gets into the product.
- The product falls and becomes damaged.

●Do not place the product on unstable surfaces. The product may be fallen and people may get hurt.



## Caution

●Do not expose the product to steam or fumes to avoid electric shocks and fires.

●Do not leave the product in high temperature places such as inside of vehicles or under direct sunlight. High temperature may cause damages to the camera, or even cause fires.

●Do not cover the product with cloth or other materials. The product may get extremely hot and the heat may cause deformations on the parts or even cause fires.

●Please avoid dropping or shocking the product as the product may be damaged.

●Do not touch the cable with a wet hand. Such action may cause electric shocks.

●Please avoid continuously contacting the surface of the camera to your skin when the camera is being used. The surface temperature of the camera may cause burns.

■Other Notices

●Please do not use the camera under strong lights such as sun light for a long period. Also please do not expose the camera under strong lights even when the product is not being used because the sensor might be damaged.

Maintenance

● Wipe the dirt on surface with soft cloth or tissue paper. Do not use alcohol, thinner or benzene to avoid damaging the surface paints.

Electro Magnetic Interference

●The camera may interference with electronic devices such as TV and radio. Please do not place the camera next to such equipment.

#### ■Export Control

The Government of Japan controls military sensitive goods and technologies including relevant dual-use goods and technologies.

This product is a Catch-all Control item subject to the Foreign Exchange and Foreign Trade Act and its relevant legislations. Except for exporting to the 27 white countries designated in the Cabinet Order, export licenses are required if the products are going to be used for military use or if the end user of the product is related to all kinds of military activities. If your circumstances cause the need to apply export licenses, please notify us before you place orders. Also, please notify us in advance if the end users or purposes of use change after the purchase and thus cause the need to apply export licenses.

\*The 27 white countries not under the UNSC Arms Embargo:

Argentina, Australia, Austria, Belgium, Bulgaria, Canada, Czech Republic, Denmark, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Republic of Korea, Luxemburg, Netherlands, New Zealand, Norway, Poland, Portugal, Spain, Sweden, Switzerland, United Kingdom, and United States

About the Japanese Security Export Controls, please refer to the webpage for Security Export Control Policy, The Ministry of Economy, Trade and Industry:  
<http://www.meti.go.jp/policy/anpo/englishpage.html>

#### ■Guarantee

To save the environment, we do not issue warranty in printed format. Instead, all records of the warranty periods, delivery dates and the customer information are well kept in our system.

For more details, please refer to the sites below:

Hardware Warranty: [http://www.artray.us/download/artray\\_warranty.pdf](http://www.artray.us/download/artray_warranty.pdf)

## 2. Introduction

ARTCAM-2020UV-USB3 is an ultraviolet camera that has high sensitivity to the wavelength band from 200nm to 1100nm.

Adopting USB3.0 interface, thus enables direct data transfer to PC without a capture card.

## 3. Main Features

- UV Detection with High Sensitivity

The adopted CMOS sensor has high sensitivity to the wavelength band from 200nm to 1100nm. Therefore, it is able to detect beyond the visible light region and visualizing things that difficult to be seen by naked eyes or common CCD / CMOS cameras.

- USB3.0 Interface

Adopting USB3.0 interface, thus enables direct data transfer to PC without a capture board or a host adapter card.

## 4. The Product


- 1) Camera
- 2) USB3.0 cable (Type A-B connector Approx. 3m)
- 3) AC adapter (AC100-240V -> DC12V)
- 4) Software CD

<Options>

C Mount Lens

# 5. Connections

## 5.1. Connecting Method (an example)



## 6. Specifications

### 6.1. Camera Specifications


#### 6.1.1. Detailed Camera Specifications

Items	
Sensor Type	Gpixel 4M Pixels CMOS Sensor GSENSE2020BSI
Resolution	2058(H) × 2056(V)
Active Resolution	2048(H) × 2048(V)
Pixel Size	6.5(H) [μm] × 6.5(V) [μm]
Active Image Size	13.3(H)×13.3(V)mm (Diagonal 18.809[mm], Approx.1.2 inch)
Wavelength	200~1100nm
Saturation Capacity/ Dark Current Noise	54ke- 1.6e- @12/11bit
A/D Resolution	11/12bit
Output Interface	USB3.0 Bulk
Output Bits	12bit
Frame Rate	30fps
Shutter Speed	56μsec ~ 1sec
Synchronization Method	Internal Synchronization
Lens Mount	C Mount
Power	DC12V External Input
Power Consumption	Approx.6W (during normal operation)
External Dimensions	71.6(W) × 61.5(H) × 51.5(D) mm ※Exclude lens, tripod and projections
Weight	Approx. 240g ※Exclude lens, tripod and projections


※All by nominal value



### 6.1.2. Dimensional Outline



### 6.1.3. Schematic Diagram of the Sensor



## 6.2. Camera's Functions

### 6.2.1. Shutter Speed

The exposure time (electronic shutter speed) of the camera can be set.

The exposure time can be calculated by the following formula:

Exposure time = the setting value of the shutter speed \* 1 hour


※1 hour = 560(Minimum) \* 1PCLK = 11.2μsec.

※1PCLK = 1/50,000,000sec. = 0.020μsec.

### 6.2.2. External Trigger Function (Optional)

This camera has an external trigger electronic circuit, which is insulated by a photocoupler, and thus enables synchronized shooting by the input signal received from the external circuit.

### Trigger input circuit diagram



R1 = 2.4kΩ (5~12V)


R2 = 4.7kΩ

The Pin Assignment of the External I/O Terminal

Pin Number	
1	GND
2	External output 1 (Strobe) ※
3	External output 2 (Trigger accepted) ※
4	External Input (-)
5	External Input (+)
6	+12V

※When outputting, please use open drain (6.5V, 50mA)


■ Details of Trigger Timing



Item No.		
t1	Effective Trigger Input Pulse	$>10\mu\text{sec.}$
t2	Time required from the starting of the External Trigger to the starting of the Internal Trigger Signals (may be delay caused the photocoupler)	$<1\mu\text{sec.}$
t3	Time required from the starting of the Internal Trigger Input to the Exposure Time	$<1\mu\text{sec.}$
t4	Strobe Time	$t_5 + t_6$
t5	Exposure Time	Exposure Time = the setting value of the Shutter Speed * 1 hour ※1 hour = 560(Minimum) * 1PCLK = 11.2 $\mu\text{sec.}$ ※1PCLK = 1/50,000,000sec. = 0.020 $\mu\text{sec.}$
t6	Time required for data transfer (from the sensor to the FPGA)	(Effective Vertical Pixels + 2) * 1 hour
t7	Time required for the transfer (from the FPGA to USB)	$>3$ hours
t8	Time required from the completion of the sensor data transfer to the completion of the USB data transfer	$>3$ hours
t9	Time required from the completion of the internal data transfer until the next trigger input becomes available	Approx. 1 hour

## 7. Spectral Sensitivity Characteristics

### 7.1. ARTCAM-2020UV-USB3




### 7.2. UV Pass Filter (U340) (Optional)

ARTCAM-2020UV-USB3 is possible to choose to install an additional filter U340, which can absorb visible wavelengths and only allow ultraviolet wavelength to pass.

Please refer to the following Spectral sensitivity line chart for detail.

(Result when superimposing the filter U340 to ARTCAM-2020UV-USB3's sensor).



## 8. Systems Requirements

### 8.1. Recommended Specifications

- Intel Chipset ICH series (6 or later version)
- CPU: Intel Core i7 6700 or higher
- Memory :  $\geq 1024\text{MB}$
- Operating System: Windows 7 or later version

### 8.2. Minimum Specifications

- USB3.0 eXtensible Host Controller
- CPU: Intel Core i5 4590 or higher
- Memory :  $\geq 512\text{MB}$
- Operating System: Windows 7 or later version



## Caution

■ Please refer the restrictions below when you use ARTCAM.

#### (1) Recommended System Requirements

If the system specifications do not meet the requirements recommended above, it may be difficult to run at the maximum frame rate.

#### (2) Use of Other USB3.0 Hardware

The data on our camera/converter is transferred in bulk mode. For this reason, when using our camera/converter, please avoid using other bulk transferred USB3.0 hardware such as Memory stick, External HDD, External DVD, CDROM and etc.

As a solution, we recommend installing a PCI USB host card to the PC and connect external USB hardware to this port only.

#### (3) USB3.0 Cable Extension

We cannot guarantee the functionality of the USB3 camera if the user adopts USB3.0 extension cables or repeaters which are not confirmed by us. With the extension cables or repeaters, the bandwidth of transfer may differ, and thus caused malfunctions such as a low frame rate or recognition failure on the camera.

What may cause the problem is that the regulation of the power lines becomes not enough, and so causes impedance mismatch on data signals.

\*For the recommended extension cable, please contact our sales department. (TEL: +81-3389-5488)

